

Aquaflex[®] ... for VCT and Quartz

UNLIMITED • moisture • installation • system

Rev: 7.24.2017

Product Information

Performance

Aquaflex Waterproof Installation System is not affected by moisture and can be used:

- insitu RH(ASTM F2170) to 100%
- MVER (ASTM F1869) >15lbs/1000sf/day
- pH (ASTM F710) to 14
- Actually cures under water.

Speed

Aquaflex Waterproof Installation System allows installation in active locations.

- Demo existing floor covering
- Prep the concrete substrate
- Install new floor covering
- Cure to foot traffic in <3hrs.

Savings

Aquaflex Waterproof Installation System is more cost effective when compared to moisture mitigation.

- Faster turnover of space.
- Repair or replacement can occur at night.
- Application of all materials at once.
- Use the same adhesive for Flash Coving.

Green

- LEED for Schools
- Collaborative for High Performance Schools
- Bio-based content, "0" zero VOC.
- California Dept. of Public Health (CDPH)

The System

Aquaflex Waterproof Installation System for Commercial VCT includes the following supplied for each project:

- Aquaflex Waterproof Adhesive
- Gundlach No. 680 CBD notch trowel for application
- Aquaflex Patch Mix - waterproof skim coat
- Aquaflex 1+1 Polymer - to be mixed with patch
- Aquaflex Remover Sponge for clean up

Surface Preparation

Moisture testing prior to installation per flooring manufacturers instruction is not a condition of warranty. **Always consult technical advise prior to installation.** Every concrete substrate is unique. Practice "clean as you work" methods.

- All concrete surfaces must be prepared prior to adhesive application per ASTM F710, level, firm, dry, smooth and free of dust, dirt, wax, cut-back, paint, grease, oil, curing agents, mold, bond breakers, residual alkaline salts, densifiers, hardeners or any other foreign material that would inhibit bond.

- Mechanical bead-blasting or concrete grinding is **NOT** required. Fill pop-outs, cracks, holes, and depressions using only **Aquaflex Waterproof Concrete Repair** products designed for the intended purpose.

- The installation area should be acclimated to at least 60°F for 24 hrs prior, during and 72 hrs following the installation. Do not install if temperatures exceed 85° F.

- The concrete **MUST** be **smooth, dry, porous and dust-free** in order to facilitate bonding with Aquaflex² PSA. If the project is a remodel, remove old adhesive with an appropriate cut-away disk attachment.

- Sand the concrete with a rotary sander fitted with dust control. Use the appropriate disc for porosity, 20 grit or better.

- **For all areas requiring full skim coat or patching use Aquaflex Waterproof Concrete Repair** products. **DO NOT OVER WATER** cementitious products; absorption of adhesive and loss of bond due to weak skim may result and warranty will void.

- Finish the **Aquaflex Waterproof Concrete Repair** products by sanding, vacuuming and giving the slab a **damp mop** for final dust removal. **DO NOT use sweeping compounds.**

Aquaflex[®]



ANTI-MICROBIAL
Prevents Mold Growth

Chemical & Physical Properties

Base:	Proprietary
Color:	Gray
Solids:	100%
Density:	9.7lbs/gal
Flammability:	Nonflammable
VOC:	0g/l, calculated
Application:	See Instructions
Shelf Life:	6 months*

*From date of manufacture and stored in original, sealed container

Application

- Acclimate all materials prior to beginning the installation process. Due to varying concrete substrate conditions **it is always recommended that an adhesion and porosity test be performed** prior to the installation process. Refer to the flooring manufacturer on proper installation method. Consult technical service for job specific recommendations.
- Use the supplied trowel with each unit, one unit covers approx. 700-800sf. Layout areas in sections, establish a section size that is easy to manage. Never spread more adhesive than can be installed in 1hr.
- **TROWEL ACCURATELY**, do not leave clumps or “snake tracks” of glue. Upon opening pail, slice open the foil bag and pour adhesive into pail. Apply adhesive until the pail is ½ empty then switch to a new trowel edge. **If adhesive is left in pail for storage, it will skin over. Prior to using stored material, remove the adhesive skin.**
- **Aquaflex adhesives should never be used as a strategy for leveling a concrete surface. Do not use Aquaflex adhesives to fill gaps, cracks, pop-outs, saw-cuts or voids of any kind in the concrete.**

Walk-On-Work Method

- For “Walk On Work” method allow adhesive to set approx 30min. Install flooring into adhesive, adjust and press flooring to activate bond. After 2hrs Aquaflex will transition to a firm set. DO NOT allow adhesive to remain open for more than 1hr. Aquaflex will grab aggressively. Areas should be protected from **heavy** traffic. Allow foot traffic after 3hrs. After 12hrs, cleaning and waxing may be initiated.
- **Do not leave gaps of adhesive at the edge line.** Clean off excess glue prior to moving on. Aquaflex has extremely aggressive bonding characteristics. Adjustments of the tile after pressed into place may not be impossible. **All set and cure times provided are approximate and can vary with site and substrate condition.**
- Roll flooring once immediately upon grab with an articulated 100lb roller lengthwise, and then again at a right angle to the first line of direction per flooring manufacturer’s instructions. **Caution: excessive rolling can create lippage with some rigid flooring products over less than smooth concrete.**

Clean-Up & Storage

Adhesive should never be used as a strategy for leveling a concrete surface. Do not use adhesive to fill gaps, cracks or voids in the concrete.

Store in a clean, dry, warm area to ensure ease of application. Shelf life is 6-months from the date of manufacture. **Reseal partial containers by covering the open pail with two pieces of plastic drop cloth, securing lid and carefully turning the pail up-side down.** To reopen turn the pail right-side up, remove lid and cut plastic liner out with cured adhesive attached. Uncured material is suitable for use.

NOTE: Aquaflex is solvent resistant when cured. Cured adhesive CANNOT be cleaned with conventional solvent or soapy water.

Practice ‘clean as you work’ methods. Call Customer Service if contamination results. **Formulators provides a safe cleaner found effective on cured Aquaflex residue.**

Statement of Performance

Prior to shipping adhesive and to insure performance, Formulators requires that a sample of the intended flooring material be submitted for bond testing. Testing is completed within 24-48hrs upon receipt of samples. Upon completion a statement of performance (SOP) will be issued. The SOP will provide detail adhesive bond performance.

Curing

Set time:	1hr
Cure suitable for foot traffic:	3hrs

Warranty


Formulators warrants Aquaflex free from defects in material and workmanship for the life of the floor when properly installed, and not to delaminate due to either elevated sub-slab or topical sources of moisture (i.e., sink overflow, leaky plumbing, roof leaks, improper floor care, etc) at **ANY** measured level.

Formulators excludes and will not pay consequential or incidental damages under this warranty. All remedies shall extend to the replacement of finished flooring materials, labor and adhesive in affected areas only and as determined by Formulators. Formulators will not pay damages resulting from poor installation, loss of bond due to the dimensional characteristics of the flooring material, telegraphing of trowel marks through the flooring material, seam failures or voids, tears, rips, misapplied or residual curing compounds, residual mold release, improperly mixed leveling or patching compounds of any kind, improper preparation technique and any other condition beyond the control of Formulators and unrelated to the integrity of the adhesive.

For complete warranty information, see Formulators Performance Warranty.



Trowel Performance Data



Coverage rate of 250sf per gallon
No. 680 CBD notch